

# SPARCO SUIT SIZE CHART

## STANDARD SUIT SIZE CHART

Refer to the chart below to determine your European size. If you fall in between sizes, opt for the larger size, or call your dealer for assistance.

EUROPEAN	USA	CHEST	WAIST	HIPS	HEIGHT	WEIGHT
130	XX-Small	27	24	29	49-53	65-80
140		30	26	31	54-57	80-100
150	X-Small	32	28	33	58-61	100-110
46		35	29	35	62-64	110-120
48	Small	36	30	36	63-65	120-130
50		38	31	38	65-67	130-140
52	Medium	39	32	39	67-69	140-150
54		41	34	41	68-71	150-165
56	Large	42	36	42	69-72	160-180
58		44	38	44	71-73	175-190
60	X-Large	45	40	45	72-74	185-205
62		46	42	47	73-75	195-225
64	XX-Large	47	44	48	74-76	215-235
66		49	46	49	76-78	225-250
68	XXX-Large	52	48	51	77-79	250-270
70	XXXX-Large	54	50	53	78-80	265-285